



深圳市飛易康科技有限公司

FSC-BT671

BT5.0 Mesh Programming User Guide

Version 1.7

FEASYCOM



Revision History

Version	Data	Notes	Author
1.1	2018/03/19	First Release	Eric
1.2	2018/05/19	Add AT+NDSEND Command	Eric
1.5	2019/01/29	Support Provisioned by self	Eric
1.6	2019/03/02	Update Quick Start chapter	Jerry
1.7	2019/05/13	Add AT+NDSUBS Command	Eric

深圳市飞易康科技有限公司
FEASYCOM

Contact Us:

Shenzhen Feasycom Technology Co., Ltd

Web: www.feasycom.com

Email:support@feasycom.com

Tel: +86-755-27924639,+86-755-23062695

Address: Room 2004-2005,20th Floor, Huichao Technology Building,
Jinhai Road, Xixiang, Baoan District, Shenzhen,518100, China.



Contents

1. Introduction	4
1.1 Terms	4
1.2 Hardware Interface	4
1.3 Supported Bluetooth Profile	4
1.4 Command Format	4
1.5 Indication Format	5
1.6 Module Default Settings	5
2. Command Table	5
2.1 General Commands	5
2.1.1 UART Communication Test.....	5
2.1.2 Read Firmware Version	6
2.1.3 Read Bluetooth Address.....	6
2.1.4 Read/Write Transmit Power	6
2.1.5 Read/Write UART Baudrate.....	7
2.1.6 Read/Write Work Mode	7
2.1.7 Soft Reboot	7
2.1.8 Restore Factory Settings	7
2.1.9 Send Data to Publication Address.....	8
2.1.10 Read / Write GATT Proxy Config.....	8
2.1.11 Read / Write Mesh Message Relay Config	8
2.1.12 Reset Mesh Network Setting.....	9
2.1.13 Read / Write Tian Mao Jing Ling Keys	9
2.1.14 Read / Write Node Publication Address	10
2.1.15 Read / Write Node Subscription Address.....	10
2.1.16 Read Node Address	11
3. Indication Table	11
3.1 General Indications	11
3.1.1 Received data Indications	11
3.1.2 Received generic on off client Message	11
3.1.3 Received generic power on off setup client message	12
3.1.4 Received generic transition time client message	12
3.1.5 Received generic lighting lightness client message	12
3.1.6 Received generic level client message	12
3.1.7 Received generic lighting ctl client message.....	12
3.1.8 Received generic lighting ctl temperature client message	13
4. Quick Start.....	13
4.1.1 Introduction	13
4.1.2 How to use FSC-BT671 in lighting solution?	14
4.1.3 How to use FSC-BT671 access Tian mao jing ling (only available in China)? ...	14
4.1.4 How to transfer data through Fsc-BT671 in Bluetooth mesh network?	15



1. Introduction

This specification presents design guidelines for software engineers that use FSC-BT630 Mesh series modules for Bluetooth requirements.

1.1 Terms

Throughout this specification:

- {} : Content between {...} is optional
- << : Content behind << represents a *COMMAND* sent from Host to Module
- >> : Content behind >> represents a *RESPONSE* sent from Module to Host

1.2 Hardware Interface

- GPIO
- PWM
- UART
- SPI Master
- I2C Master/Slave
- Analog Input / Output

1.3 Supported Bluetooth Profile

- GATT Server (Generic Attribute Profile)
- Mesh (Mesh Profile)

1.4 Command Format

AT+ Command {=Param1{, Param2{, Param3...}}} <CR><LF>

- All commands start with "AT", end with <CR><LF>
- <CR> stands for "carriage return", corresponding hex is 0x0D
- <LF> stands for "line feed", corresponding hex is 0x0A
- If command has parameter, parameter keep behind "="
- If command has multiple parameters, parameter must be separated by ","
- If command has response, response start with <CR><LF>, end with <CR><LF>
- Module will always report command's execution result using "OK" for success or "ERROR" for failure

e.g.



1. Read module's BR/EDR local name

```
<< AT+NAME  
>> +NAME=Feasycom  
>> OK
```

2. Write a baudrate which is not supported

```
<< AT+BAUD=0  
>> ERROR
```

1.5 Indication Format

<CR><LF>+ Indication {=Param1{, Param2{, Param3...}}}<CR><LF>

- All indications start with <CR><LF>, end with <CR><LF>
- If indication has parameter, parameter keep behind “=”
- If indication has multiple parameters, parameter must be separated by “,”

e.g.

1. Received “1234567890” from node 4315
>> +DATA=4315,CA00,10,1231231231

1.6 Module Default Settings

Physical UART Setting

115200/8/N/1

2. Command Table

2.1 General Commands

2.1.1 UART Communication Test

Format: AT
Response: OK
Description: Test the UART communication between HOST and Module after power on, baudrate changed, etc.
Example: UART communication test



```
<<    AT  
>>    OK
```

2.1.2 Read Firmware Version

Format: AT+VER

Response: +VER=Param1

Param1: Firmware version

Example: Read module's firmware version

```
<<    AT+VER  
>>    +VER=1.1.3,FSC-BT671,Mesh  
>>    OK
```

2.1.3 Read Bluetooth Address

Format: AT+ADDR

Response: +ADDR=Param1

Param1: Local Bluetooth address

Example: Read module's Bluetooth address

```
<<    AT+ADDR  
>>    +ADDR=DC0D308B42FA  
>>    OK
```

2.1.4 Read/Write Transmit Power

Format: AT+TXPOWER{=Param1}

Param1: TX power (0.1dBm steps, for example the value of 10 is 1dBm and 55 is 5.5dBm, default:200)

Response: + TXPOWER =Param1

Param1: TX power (0.1dBm steps, for example the value of 10 is 1dBm and 55 is 5.5dBm)

Example: Read module's tx power

```
<< AT+TXPOWER  
>> +TXPOWER=200  
>> OK
```

2.1.5 Read/Write UART Baudrate

Format: AT+BAUD{=Param1}

Param1: Baudrate (2400/4800/9600/19200/38400/57600/115200/230400/256000/460800/512000/921600, default:115200)

Response: +BAUD=Param1

Description: Need Reset Module.

2.1.6 Read/Write Work Mode

Format: AT+MODE{=Param1}

Param1: mode (0, app mode, provisioned by mobile app. 1, tian mao jing ling mode, provisioned by tian mao jing ling. 2, Self-organizing network, provisioned by self. default:0)

Response: +MODE=Param1

Description: Config module work mode.

2.1.7 Soft Reboot

Format: AT+REBOOT

Description: Module software reboot.

2.1.8 Restore Factory Settings

Format: AT+RESTORE



Description: Module restore all factory settings then reboot

2.1.9 Send Data to Publication Address

Format: AT+NDSEND=Param1, Param2

Param1: Data size

Param2: Data

Response: OK

Description: Send Data to publication address, default address is 0xCA00.

Example: Send Data 12345 to publication address without ack

<< AT+NDSEND=5,12345

>> OK

2.1.10 Read / Write GATT Proxy Config

Format: AT+NDPROXY<=Param1>

Param1: enable proxy (0, disable GATT proxy 1, enable GATT proxy)

Response: OK

Description: Enable GATT proxy allow mobile phone connect and control mesh network.

Need reboot

Example: Enable GATT Proxy

<< AT+NDPROXY=1

>> OK

2.1.11 Read / Write Mesh Message Relay Config

Format: AT+NDRELAY<=Param1, Param2, Param3>

Param1: enable message relay (0, disable; 1, enable)

Param2: relay count

Param3: relay interval

Response: OK

Description: Enable and setting relay feature. Need reboot

Example: Enable relay feature

```
<<    AT+NDRELAY=1,1,1  
>>    OK
```

2.1.12 Reset Mesh Network Setting

Format: AT+NDRESET

Response: OK

Description: Removes all keys and other settings that have been configured for this node.

Example: Reset Mesh Network Setting

```
<<    AT+NDRESET  
>>    OK
```

2.1.13 Read / Write Tian Mao Jing Ling Keys

Format: AT+TMCFG<=Param1, Param2, Param3>

Param1: production id (Alibaba distribution)

Param2: production secret (Alibaba distribution)

Param3: address (Alibaba distribution)

Response: OK

Description: Config production id, production secret and address to module. Need reboot

Example:

```
<<    AT+TMCFG=00000112, 60e989e27937b208cacf1c029442ec81,78da076bcf6c  
>>    OK
```

2.1.14 Read / Write Node Publication Address

Format: AT+NDPUBL<=Param1 >

Param1: publication Address

Response: OK

Description: Config node publication Address. AT+NDSEND will send data to publication address. Default Publication address is 0xCA00.

Example:

```
<<  AT+NDPUBL=CA00  
>>  OK  
<<  AT+NDPUBL  
>>  +NDPUBL=CA00  
      OK
```

2.1.15 Read / Write Node Subscription Address

Format: AT+NDSUBS<=Param1, Param2>

Param1: 0, delete subscription address. 1, add new subscription address.

Param2: subscription address.

Response: OK

Description: Add address to subscription list, delete address from subscription list or inquiry subscription list.

Example:

```
<<  AT+NDSUBS=0,CA00  
>>  OK  
<<  AT+NDSUBS=1,CA00  
>>  OK  
<<  AT+NDSUBS  
>>  +UARTSUBS={  
      +UARTSUBS=CA00  
      +UARTSUBS=}  
      OK
```

2.1.16 Read Node Address

Format: AT+NDID
Response: OK
Description: Get Current Node Address, if not provisioned, 0xFFFF will return.
Example: << AT+NDID >> +NDID=0013 OK

3. Indication Table

3.1 General Indications

3.1.1 Received data Indications

Format: +DATA=Param1, Param2, Param3, Param4 Param1: Source address Param1: Destination address Param2: Data Size Param3: Data
Example: Received data from 4315 (vendor model) << +DATA=4315,CA00,10,1231231231

3.1.2 Received generic on off client Message

Format: +ONOFF=Param1 Param1: 0, off. 1, on. 2, not support
Example: Received generic on off client message. << +ONOFF=0

3.1.3 Received generic power on off setup client message

Format: +ONPOWERUP=Param1

Example: Received generic power on off setup client message.

<< +ONPOWERUP=0

3.1.4 Received generic transition time client message

Format: +TRANSTIME=Param1

Example: Received generic transition time client message.

<< +TRANSTIME=2

3.1.5 Received generic lighting lightness client message

Format: +LIGHTNESS=Param1

Example: Received generic lighting lightness client message.

<< +LIGHTNESS=FFFF

3.1.6 Received generic level client message

Format: +LEVEL=Param1

Example: Received generic level client message.

<< +LEVEL=FFFF

3.1.7 Received generic lighting ctl client message

Format: +CTL=Param1,Param2,Param3

Param1: lightness

Param2: temperature

Param3: deltauv



Example: Received generic lighting ctl client message.

<< +CTL=FFFF,5555,4444

3.1.8 Received generic lighting ctl temperature client message

Format: +CTLTEMP=Param1,Param2

Param1: temperature

Param2: deltauv

Example: Received generic lighting ctl temperature client message.

<< +CTL=5555,4444

4. Quick Start


4.1.1 Introduction

FSC-BT671 provides Bluetooth networking solution, compatible with Bluetooth mesh, and supports Bluetooth 5.0.

FSC-BT671 support flow sig models and one vendor model use for data throughput:

MESH_GENERIC_ON_OFF_SERVER_MODEL,
MESH_GENERIC_POWER_ON_OFF_SETUP_SERVER_MODEL,
MESH_GENERIC_TRANSITION_TIME_SERVER_MODEL,
MESH_LIGHTING_LIGHTNESS_SERVER_MODEL,
MESH_GENERIC_LEVEL_SERVER_MODEL,
MESH_LIGHTING_CTL_SERVER_MODEL,
MESH_LIGHTING_CTL_SETUP_SERVER_MODEL,
MESH_LIGHTING_CTL_TEMPERATURE_SERVER_MODEL,

4.1.2 How to use FSC-BT671 in lighting solution?



In this solution, FSC-BT671 can be provisioned by mobile app, receive control signal from app and output PWM signal to drive LED. 2 PWM channels supported by default.

- 1) Connect VDD, GND, PIO2, PIO9, PIO10.
 - PIO2 used for restoring module network settings to defaults
 - PIO9, PIO10 used for PWM output
- 2) Set PIO2 to high level, reboot module, wait 1 second, so that module could restore network settings, then set PIO2 to low level
- 3) Download Bluetooth Mesh app, provision module in mesh network
- 4) Control Lightness in app
- 5) Module will output different PWM signals due to different control instructions

4.1.3 How to use FSC-BT671 access Tian mao jing ling (only available in China)?

In this solution, FSC-BT671 can be provisioned by tian mao jing ling, receive control signal from tian mao jing ling and output PWM signal to drive LED, 2 PWM channels supported by default.

- 1) Connect TX, RX, VDD, GND, PIO2, PIO9, PIO10
 - PIO2 used for restoring module network settings to defaults
 - PIO9, PIO10 used for PWM output
 - UART_TX and UART_RX used for interacting with module by AT commands



- 2) Set PIO2 to high level, reboot module, wait 1 second, so that module could restore network settings, then set PIO2 to low level
- 3) Send AT+MODE=1 to change module work mode. UART default settings are 115200/8/N/1
- 4) Send AT+TMCFG=<pid>,<p_sec>,<addr> to configure module
- 5) Let tian mao jing ling provision module
- 6) Give audio instruction to tian mao jing ling, such as “亮一点”, “暗一点”, etc.
- 7) Module will output different PWM signals due to different control instructions

4.1.4 How to transfer data through Fsc-BT671 in Bluetooth mesh network?

In this solution, FSC-BT671 can be provisioned by itself, receive message from network and send message to network.

- 1) Connect TX, RX, VDD, GND, PIO2
 - PIO2 used for restoring module network settings to defaults
 - UART_TX and UART_RX used for interacting with module by AT commands
- 2) Send AT+MODE=2 to change module work model. UART default settings are 115200/8/N/1
- 3) Send AT+REBOOT to reset module
- 4) when module received data packet, module will send +DATA=<source address>,<destines address>,<len>,<data> to host
- 5) If host need to send data through module to other devices in mesh network, host shall send AT+NDSEND=<len>,<data> to module, then all the other devices in mesh network will receive the data